

## APPLICATION



If contaminated, use a claybar to clean the paint and wheels. If paint correction is required do so before application.



Wash and completely dry surfaces to be coated.



Clean the paint using a 50% IPA (isopropyl alcohol) to water mix in a trigger sprayer. Mist the paint then wipe down with a microfiber towel.



Wipe on coating by hand using a sponge or coating block, panel by panel. After wiping on wait 30-60 seconds to flash (depending on temp) then buff off with a microfiber towel.



Wait 20 minutes before driving, and 6 hours before getting wet.

# MAX

CERAMIC NANO COATING

## PRODUCT OVERVIEW



System X Max provides super-slick and glossy paint protection with previously unachievable levels of durability, hardness, and chemical resistance. Thicker than any coating, Max™ is ready to protect in the most extreme environments.

System X Max has a **LIFETIME WARRANTY** on automobiles & motorcycles, 5-Year warranty on boats, 3-Year warranty on Powersports, Rv's, & fleet vehicles, and 2-Year warranty on aircrafts when installed by an Accredited Installation Center and annual inspection requirements are met.



## TECHNICAL DATA

<b>EFFECTIVENESS</b>	10+ years depending on environmental factors
<b>PENCIL HARDNESS</b>	9H
<b>APPLICATION</b>	Wipe on / buff off application or use HVLP gun with 0.8mm tip and buff off by hand
<b>BOTTLE SIZE</b>	20 mL, 65 mL, 275 mL, 4L
<b>SHELF TIME</b>	1 year from shipment date when unopened and stored dry at 18°C (64°F) to 23°C (73°F)
<b>APPEARANCE</b>	Clear / High Gloss
<b>FILM THICKNESS</b>	Up to 0.9 mil
<b>CHEM. RESISTANCE</b>	Outstanding
<b>TEMP. RESISTANCE</b>	> 538°C (1000°F)
<b>SALT SPRAY</b>	<b>(ASTM B117)</b> @ 35°C (95°F), 5% salt concentration, > 400 hrs to first signs of corrosion
<b>ADHESION CROSS-CUT TAPE</b>	<b>(ASTM D3359)</b> 5b (0%, none)
<b>MANDREL BEND</b>	<b>(ASTM D522)</b> 0% @ 180° rotation
<b>IMPACT</b>	<b>(ASTM D2794)</b> 80/80 in/lbs
<b>COVERAGE</b>	50 sq feet (4.645 sq meters) per 100ml
<b>DRY TIME</b>	40 minutes
<b>CURE TIME</b>	Initial cure in 4 hours, full cure in 3 days